

Thanks for choosing KC HiLITES products; your satisfaction is very important to us. If you have any questions regarding this product or any other KC HiLITES products, please contact us at (888) 689-5955 or visit [kchilites.com](http://kchilites.com).

### PARTS INCLUDED

- 1 - 50" LED light bar with wiring
- 1 - Above windshield light mounting bracket set
- 10 - M8 x 1.25 x 30 mm Black Zinc Bolts
- 10 - M8 Black Zinc Washers
- 2 - Protective Rubber Gaskets

### MOUNTING THE BRACKETS

1. Remove the upper five of the six Torx head bolts from each of the windshield frame brackets. These are located in the lower corner of the driver and passenger side of the windshield.
2. Align the rubber protective gasket with the holes on the vehicle and secure temporarily with small pieces of scotch tape or similar.
3. Place the bracket on the gasket and start each of the five M8 bolts and washers. Tighten all by hand. Remove the tape used to secure and then tighten all bolts.
4. Repeat procedure for opposite side of vehicle.
5. Install your 50" C50 LED bar to the brackets and wire it according to the instructions included with the LED bar.



### YOU'RE DONE